

(Dwg. 45588175)





45585163 Edition 3 August 2011

2115TiMAX and 2125TiMAX Series Air Impactool[™] - Parts List

tem	Part Description	Part Number		Part Description	Part Number
*	Housing Assembly		19	Bushing, Hammer Case	2112-641
	for model 2115TiMAX	2115TiMAX-A40	*	Hammer Case Assembly	2115TiMAX-D72
	for model 2115QTiMAX	2115QTiMAX-A40	19	Bushing, Hammer Case	
	for model 2125QTiMAX	2125QTiMAX-A40	20	Hammer Case	
	for model 2115PTiMAX	2115PTiMAX-A40	21	Grease Fitting	
	for model 2125PTiMAX	2125PTiMAX-A40	21	Grease Fitting	130SR-188
1	Housing			Trigger Assembly	2135-D93B
3	Warning Label		22		
4	Information Label		22A	O-Ring, Trigger	
23	Gasket, Motor			Gasket, Motor	2112-283
*	Reverse Valve Assembly			Reverse Valve Assembly	2131-A329
29	Button Kit		24		
	Screw, Hammer Case (4 required)	2115-638	24A		
	Warning Label	WARNING-2-99	24B		
	Information Label	101010233		Inlet Bushing Assembly	2135-D565A
	for model 2115TiMAX	2115TiMAX-300	26		
	for model 2115 Tim AX	2115QTiMAX-300	27	Inlet Clip	2131-57
	for model 2125QTiMAX	2125QTiMAX-300	28	Inlet Parts Kit	2135-K303
	for model 2125QTIMAX	2115PTiMAX-300	28A		
	for model 2125PTiMAX	2125PTiMAX-300	28B	O-Ring, Seal	
	Power Regulator Assembly	2115-D249A	28C	Throttle Spring	
5	Power Regulator	2113-D249A	28C	Throttle Valve	
5A			28D	Valve Seat	
	Retaining Ring	4E-6	20E	Seat Support	
	Ball Bearing (Cylinder)	R00H-97	28G	Retainer	
	Cylinder	2112-3		Button Kit	2115-K75RD
	Rotor	2112-5	29 29A	Forward Button	2113-K/3KD
	Vane Pack (set of 7)	2115-33 2115-42A-7	29A 29B		
	End Plate	2113-42A-7		Silencer (for models 2115QTiMAX, 2125QTiMAX,	
	Ball Bearing (End Plate)	2131-97	50	2115PTiMAX and 2125PTiMAX)	2115Q-311
	Hammer Case Gasket	2131-97	*	Tune-Up Kit	2115-TK2
*	Hammer Case Gasket Hammer Mechanism Kit	2115-36 2115-THK2	5A		2115-1K2
		2115-1HK2	5A 6		
14	Hammer (2)				
15 15A *	Hammer Frame		7	Ball Bearing (Cylinder)	
	Hammer Pin (2)		10		
	Anvil Assembly		12	Ball Bearing (End Plate)	
	for models 2115TiMAX and 2115QTiMAX		13	Hammer Case Gasket	
	for model 2125QTiMAX	2112-A726	22A		
	for model 2115PTiMAX	2112P-A626	23		
	for model 2125PTiMAX	2112P-A726	24A		
16	Anvil		24B		
	Socket Retainer Kit		28		
	Socket Retainer Kit			Kit, Piped-Away Exhaust	2115-K284
	for models 2115TiMAX and 2115QTiMAX	2115-K425		Inlet Clip Removal Tool	2131-322
	(3/8" Ring-type)			Air Care Kit (grease gun, grease, oil)	115-LBK1
	for model 2125QTiMAX (1/2" Ring-type)	2125QTi-K425		Grease (replacement tube for -LBK1)	115-4T
	O-Ring			Air Tool Oil (4 oz. bottle)	10Z4
	Socket Retainer			Grease (1 lb can)	105-1LB
† 18	Socket Retainer Kit			Grease (8 lb can)	105-8LB
	for model 2115PTiMAX (3/8" Pin-type)	2115PTi-K425	*	Grease Gun	R000A2-228
	for model 2125PTiMAX (1/2" Pin-type)	2125PTi-K425			
	Retainer Spring				
	Socket Retainer Pin				

Not illustrated.

† To keep downtime to a minimum, it is desirable to have certain repair parts on hand. We recommend that you stock one (pair or set) of each part indicated by a (†) for every four tools in service.

Parts and Maintenance

When the life of the tool has expired, it is recommended that the tool be disassembled, degreased and parts be separated by material so that they can be recycled.

Tool repair and maintenance should only be carried out by an authorized Service Center.

Refer all communications to the nearest Ingersoll Rand Office or Distributor.

Related Documentation

For additional information refer to:

Air Impact Wrench Product Safety Information Manual 04580916. Air Impact Wrench Product Information Manual 45585155.

Manuals can be downloaded from www.ingersollrandproducts.com.



www.ingersollrandproducts.com © 2011 Ingersoll-Rand Company

45585163 Edition 3 August 2011